



SWAY BAR INSTALLATION

DISASSEMBLY AND REMOVAL

- 01** Remove the links that are connected to your arm and to the sway bar.
- 02** Remove the sway bar brackets. There are four nuts on the inside of the frame that need to be removed. On the driver's side, slide the sway bar assembly out.

INSTALLATION AND REASSEMBLY

- 01** Take your SANDCRAFT sway bar mounts and bolt them into the frame in the original location. Place the billet mounts so that the shoulder of the bushing is facing inside (or toward each other on each side).
- 02** The sway bar tube will slide through the first mount. Now is the time to slide both of the collars (supplied) over the tube. Slide the tube through the other side.
- 03** At this point you will need a tape measure to center the bar to the mounts. Measure from the bracket to the end of the tube and make sure there is an even amount of tube on each side.
- 04** Attach the SANDCRAFT sway bar arms to the tube so that the logo is facing outside. Now tighten the pinch bolt on the arm where it attaches to the tube.
- 05** The links will now be attached to the sway bar arm first. Tighten bolts connecting links to the arm.
- 06** Now the bottom link on one side will bolt into the trailing arm location. The other link arm will need to be adjusted to be able to bolt in to the trailing arm.
- 07** Set both adjustable links to the same overall length from center to center of the bolts. Tighten down the jam nuts and double check all work.