

INSTALLATION INSTRUCTIONS

SANDCRAFT A-ARM BUSHING & SLEEVE KIT - PRO R



TOOLS REQUIRED:

- Grease
- Floor jack & jack stands
- Rubber mallet
- Drill
- Torque wrench
- 15mm wrench (2)
- Lock ring pliers
- Lug wrench

